

System Block Diagram.

Fig. 1





Fig 2

High Deficition Resthrough Block Diagram



High Definition Transmission

Fig. 3




Fig. 5




Fig. 6

700
A sink device initiates a key exchange -705
The Stb Self DCM indicates to the HNS Manager that -710 a Key exchange is Commencing.
The HIUS Manager indicates the Key exchange to the -715 copy protection Module.
The copy protection module authenticates the sink device -720 by sending AV/c commands using the services of the OSDFCM

Fig. 7